



Ultra-Lube 2001 Lubrication/Re-Lubrication Flow Chart

1. Lower volume to filter out any background noise.
2. If Zerk fitting is connected to bearing housing through tubing, allow for tube volume.